# Random Pulse Generator

The Random Pulse Generator node, for all the time the **Gate** connector value is 1, generates pulses with random times for ON and OFF.
The random time for ON will be included between **Minimum factor for ON** property and **Maximum factor for ON** property; the random time for OFF will be included between **Minimum factor for OFF** property and **Maximum factor for OFF** property.

Behaviour of Random Pulse Generator

From:
http://www.thinknx.com/wiki/ - **Learning Thinknx**

Permanent link:
http://www.thinknx.com/wiki/doku.php?id=lm_timer_random

Last update: **2019/03/20 17:04**