


And



The And node sends 1 on the output only when all the inputs are 1.

Input 1	Input 2	Output
0	0	0
0	1	0
1	0	0
1	1	1

From:

<http://www.thinknx.com/wiki/> - **Learning Thinknx**

Permanent link:

http://www.thinknx.com/wiki/doku.php?id=lm_logic_and&rev=1506441757

Last update: **2019/03/20 17:03**

