

Migration to Thinknx UP

- [Introduction](#)
- [What's new?](#)
 - [General updates](#)
 - [Objects upgrades](#)
- 3. [How to migrate?](#)

Introduction

Thinknx UP is a completely redesigned version of the Classic Thinknx software. It includes additional features for the system integrator and the end user. In order to use Thinknx UP, it is important to update both Thinknx Server and Thinknx Client as seen in the table below:

Server \ Client	Client	
	Classic	UP
Classic (version 1.1.9.xx)	ok	X
UP (version 1.1.10.xx)	ok	ok

Figure 1: Thinknx Compatibility



The table above is applicable to all features except for Push Notifications. They only work when both server and clients are using the same Thinknx version.

• What's New?

General updates

Improved performance of the application (in terms of speed and startup) and unified platform for a more consistent experience on all devices



Figure 2: Thinknx Platform

Re-designed interface of the “Project Configuration Wizard”




Figure 3: Project Configuration Wizard

High customization of the icons

A large set of SVG icons is now integrated inside the Configurator, allowing the user to:

- Scale without losing quality
- Choose the background's opacity
- Change the background's color and shape
- Modify the background's border color and thickness




Figure 4: Graphic customization

Possibility to change the below for each project:

- Aspect ratio (4:3 - 16:9 - Envision - Balanced)
- Orientation (landscape - portrait)
- Theme (dark - White)

It is important to note that phones, tablets, and Envisions have different screen sizes and resolutions, therefore the project will not be displayed exactly the same on all these devices. For example, if an aspect ratio of 4:3 has been used while creating the project, and if viewed on a 16:9 device, additional spaces shall be inserted to the left and right of the project to accustom for the bigger screen.

Therefore, it is better that the integrator chooses the most favorable aspect ratio depending on the devices used in each project. If multiple types are used, then the best option would be to select the Balanced option.




Figure 5: Aspect Ratio

Ability to edit multiple selections at once

By selecting multiple objects, it is now possible to edit their color, background or other common parameters in just one attempt.




Figure 6: Edit multiple selections

Ability to lock objects on the interface




Figure 7: Lock objects

Improved KNX group search utility




Figure 8: KNX search utility

• Objects Upgrades

◦ Switch object:



- New redesigned popup window
- For Dimmer type, possibility to have a side bar to view the dimmer's feedback when popup is closed

◦ Shutter object:



- New redesigned popup window
- Possibility to rotate the blind from the same icon

◦ Scene object:



- New redesigned popup window
- Possibility to view/arrange/delete recorded actions
- Possibility add "pause" time between actions

◦ RGB object:



- New redesigned popup window
- Possibility to control "White" channel
- Possibility to store unlimited number of favorite colors
- Possibility to manage color sequences with changeable time interval between colors

◦ Thermo Comfort object:



- New redesigned popup window
- Possibility to change the valve type between 1 bit and 1 byte
- Possibility to control the fan speed
- Possibility to parameterize the setpoint between "Absolute" and "Relative"

◦ Analog Value object:



- Possibility to change the level colors when displayed as "bar"
- Possibility to

display
the
values
as a
"circle"
" and
chang
e its
color,
border
thickn
ess,
and
start/e
nd
angle

o



C
a
m
e
r
a
o
b
j
e
c
t
:

■

P
o
s
s
i
b
i
l
i
t
y
t
o
t
e
s
t
t
h
e

c
a
m
e
r
a
i
n
s
i
d
e
t
h
e
C
o
n
fi
g
u
r
a
t
o
r
e
i
t
h
e
r
i
n
"
L
o
c
a
l
"
o
r
"
R
e
m
o
t
e
"

m
o
d
e
▪
N
e
w
d
e
c
o
d
e
r
w
i
t
h
b
e
t
t
e
r
p
e
r
f
o
r
m
a
n
c
e
f
o
r
H
.
2
6
4
a
n
d
H
.
2
6

5



o
I
n
t
e
r
c
o
m
o
b
j
e
c
t
:

■
P
o
s
s
i
b
i
l
i
t
y
t
o
m
a
k
e
i
n
t
e
r
n
a
l
S
l
i
p
c
a
l

I
s
b
e
t
w
e
e
n
r
e
g
i
s
t
e
r
e
d
u
s
e
r
s



◦
A
d
v
a
n
c
e
d
I
n
t
e
g
r
a
t
i
o
n
:

■

P
u
b
l
i
c
A
P
I
f
o
r
i
n
t
e
g
r
a
t
i
o
n
w
i
t
h
t
h
i
r
d
p
a
r
t
y
s
y
s
t
e
m
s

■

A
d
d
i
t
i

o
n
a
l
s
y
s
t
e
m
o
b
j
e
c
t
f
o
r
i
n
t
e
g
r
a
t
i
o
n
w
i
t
h
I
F
T
T
T
(
s
e
e
d
e
t
a
i
l
s
[h](#)

e
r
e
)

How to Migrate?

- Step 1.
Download Thinknx UP Configurator [or here](#).
- Step 2.
Click on Open -> Import and select your project file (.erg)

Exported projects from the Classic Configurator have the extension “.erg”, while Thinknx UP projects are defined by the “.tup” extension.

- Step 3.
Once the projec

t is
open,
arran
ge
and
modif
y the
interf
ace
as
neede
d.

After
importing
an “.erg”
project,
always
double
check that
all objects
inside the
project
have been
imported
correctly.

- Step
4.
Click
on the
botto
m
right
of the
Confi
gurat
or to
searc
h for
your
Think
nx
server
.
- Step
5.
Once
server

is
locate
d,
click
on
“Firm
ware
updat
e” to
open
the
updat
e
windo
w.

A simple
update of
the server
from its
web
interface is
not enough
to migrate
to Thinknx
UP. It will
only search
for the
updated
version of
the Classic
Thinknx
(1.1.9.xx).

- Step
6.
Click
on
“Chec
k for
Updat
e” to
searc
h for
an
availa
ble
updat
e

online
, or
locate
a file
locally
on the
PC.

- Step 7.
Once
Think
nx UP
versio
n is
locate
d
(1.1.1
0.xx)
on the
intern
et,
click
on
“Dow
nload
intern
et
availa
ble
versio
n”.
The
versio
n will
now
be
availa
ble
locally
on the
comp
uter.





Fig
ure 9:

Download
update

- Step 8.
Close the firmware updater and open it again.
- Step 9.
Make sure that you read "1.1.1 0.xx" next to the "Locally available" status.
- Step 10.
Click on "Update locally available" to migrate the server to

Think
nx UP.
Once
finish
ed,
the
logs
will
indica
te
that
server
is now
updat
ed to
versio
n
1.1.10
.xx.



Figu
re
10:
Insta
ll
upda
te

- Step
11.
Uploa
d
projec
t to
the
updat
ed
server
- Step
12.
Downl
oad
Think
nx UP

client:

- App - Download App
- Android - Download App
- Windows - Download

n
l
o
a
d
P
l
a
y
e
r

■ M
a
c
-
D
o
w
n
l
o
a
d
P
l
a
y
e
r

3. Step
13. If
Envisi
on
scree
n is
used,
go to
“Setti
ngs”,
select
the
“Opti
ons”
tab
and
click
on the
butto
n
“Load

Think
nx
UP”.

4. Step
14.
Make
sure
Envisi
on is
updat
ed to
the
latest
firmw
are.

Migra
tion
from
Classi
c to
UP
might
requir
e a
reboo
t of
the
Envisi
on

o
S
t
e
p
1
5
.
E
n
j
o
y
T
h
i
n
k

n
x
U
P
!

