**ThinKnx Cloud** 

# Thinknx Cloud is used for several services in the Thinknx system:



Figure 1: Thinknx Cloud Services

• **Modifying and updating the project remotely on server and clients**. Using the Thinknx Configurator, the integrator or installer can deploy the modified project to the Cloud. The server will automatically be alerted and will reboot once the new version is downloaded, and all the clients will get a notification that a newer version of the project is available to download on their devices.

# $\circ\,$ How to enable it?

 Step 1. Enable Thinknx Cloud on server. Go to the server's web page, click on Server -> ThinknxCloud, and click on Enable Thinknx Cloud. Enter your email and a new password.



Figure 2: Enable Thinknx Cloud on Server

\* Step 2. Enable Thinknx Cloud in Configurator. Inside the Configurator, click on the System tab, then System, and enable Thinknx Cloud in the properties below. Enter the same password used in step 1. Enable Automatic Server Update, Automatic Authentication, and Automatic Connection.

Label	System		۸
Server type	Compact		
Serial number	000000-0000-07		
Password	ServerPassword		
ThinknxCloud	Enabled		_
Password for ThinknxCloud	MainCloudPassword		=
Automatic server update	Enabled		
Automatic authentication	Enabled		
Automatic connection	Enabled	-	
Cloud connection policy	Local and Cloud		
KNX address			
External IP address			
Server client port	7550		
Local IP address			
System name			

Figure 3: Enable Thinknx Cloud in configurator

• Automatic client connection. In the absence of a fixed external IP address at the automated location, it is possible to use Thinknx Cloud to allow remote access to the project for all clients. They will be able to monitor their entire house from anywhere using only the Internet at no additional cost. However, some services might not be available for this option, such as answering a SIP call remotely or viewing a local IP camera from outside the house.

### • How to enable it?

• Follow same steps as previous service.

2. Database for live data storage. Every project will require to save some data for continuous monitoring, chart visualization, or monthly reporting. This data will be saved for each single server in a dedicated space on the cloud. Every time a Thinknx application is launched, the server will contact the cloud to retrieve this data, and update them as they change. Only a small amount of values is saved locally on the server.

### • How to enable it?

- This service is available the moment Thinknx Cloud is enabled following the steps in the previous services.
- To view the amount of data used in the project so far, you can go to the server's web page, click on the server tab, then choose Thinknx Cloud. The amount of used data can be read in the status messages.

# ThinknxCloud Configuration



From this page is possible to modify ThinknxCloud services parameters.

### **Current settings :**

- Cloud enabled : Enabled
- Cloud connection : Connection available and established
- Email : ingrid.hayek@thinknx.com
- MyThinknx enabled : Enabled
- MyThinknx ID : ingridcompact
- Subscription code:
- Subscription expiration : None
- Available services : None
- Integration Kit enabled : Enabled
- Integration Kit key :

#### Used space : 1.00 KiB

Available space :





If the server was bought without the Report and Gateway license, it is only possible to store 20 MB of data on the Thinknx Cloud. Once the license is purchased, saving data becomes unlimited.

- **Dynamic DNS**. This option is used in the absence of a *fixed* external IP address at the automated location. Instead, the public IP address is accessible but changes after each connection renewal or on router reboot. Thinknx offers a free dynamic DNS service configurable from the server's web page. With this service, a host name (such as *myhome.my.thinknx.net*) is associated to the public IP address of the router and the server will always be reachable through this host name no matter what the public IP address is.
  - How to enable it?
    - Step 1. Enable Thinknx Cloud on server. Go to the server's web page, click on Server -> ThinknxCloud, and click on Enable Thinknx Cloud. Enter your email and a new password.
    - Step 2. Enable myThinknx ID. Using the same page, click on the button Enable myThinknx, and enter your identifier. MyThinknx identifier will be used to reach

## your server. The full name will be: *identifier.my.thinknx.net*.

Enable/Disable MyThinknx	×
You are going to enable MyThinknx service for your server. Please provide the followind data:	
MyThinknx identifier will be used to reach your server. The full name will be: xxx.my.thinknx.net where xxx is the identifier that you are inserting here. The identifier length should be between 8 and 32 characters. Only standard chars are allowed [0-9; a-z; A-Z; _].	be
Insert MyThinknx identifier	
Enable Disable Cancel	

Figure 5: Enable myThinknx ID

\* Step 3. Configure external IP address. Inside the Configurator, go to the system tab, click on System, and go to the External IP Address property. Write down the following "identifier.my.thinknx.net", replacing the identifier with the myThinknx ID configured in step 2.

\* Step 4. Port forwarding on router. To enable client applications to open remotely, a configuration should be done on the router installed in the same network as the Thinknx server. All external requests should be forwarded to the local IP address of the server using port 7550.

From: http://www.thinknx.com/wiki/ - Learning Thinknx



Permanent link: http://www.thinknx.com/wiki/doku.php?id=thinknx\_cloud&rev=15560877 Last update: 2019/04/24 08:36

Learning Thinknx - http://www.thinknx.com/wiki/