



# Pulse Width Modulator



The Pulse Width Modulator node converts an analog input into a pulse where the ON/OFF ratio depends on the modulated value of the **Input** connector. The node computes the ratio of the **Input** value with the **Input Min.** property and the **Input Max.** property and applies it to the **Period** of the output pulse to determine the ON time. The ratio is calculated at every expiration of the **Period** and thus it considers the actual value of the **Input** connector in that moment.



Behaviour of PWM

From: <https://www.thinknx.com/wiki/> - Learning Thinknx

Permanent link: [https://www.thinknx.com/wiki/doku.php?id=lm\\_analog\\_pwm](https://www.thinknx.com/wiki/doku.php?id=lm_analog_pwm)

Last update: 2019/03/20 17:04

